

## Coast Guard, DHS

## § 117.1035

(4) If the bridge is not opened during a particular scheduled opening per paragraph (d)(3)(ii) of this section and a vessel has made prior arrangements for a delayed opening, the draw tender may provide a single opening up to 30 minutes past that scheduled opening time for that signaling vessel, except at 2:30 p.m. The draw tender may provide a single opening up to 20 minutes past the 2:30 p.m. scheduled opening time for a signaling vessel that made prior arrangements for a delayed opening. A vessel may make prior arrangements for a delayed opening by contacting the Berkley Bridge Traffic Control room at (757) 494-2490.

[CGD 82-025, 49 FR 43463, Oct. 29, 1984, as amended by CGD 05-88-13, 53 FR 20321, June 3, 1988; CGD 5-89-43, 54 FR 30039, July 18, 1989; CGD5-90-023, 55 FR 23434, June 8, 1990; CGD05-04-209, 70 FR 22254, Apr. 29, 2005; CGD05-05-049, 70 FR 68337, Nov. 10, 2005; USCG-2009-0754, 75 FR 47464, Aug. 6, 2010]

EFFECTIVE DATE NOTE: At 75 FR 47464, Aug. 6, 2010, § 117.1007 was amended by suspending paragraphs (b) and (c) and adding new paragraph (d), effective Sept. 4, 2010 through Oct. 5, 2012.

### § 117.1011 Great Wicomico River.

The draw of the S200 bridge, mile 8.0 at Tipters, shall open on signal; except that, if an opening is desired from 6 p.m. to 6 a.m., the drawtender on duty shall be notified before 6 p.m.

### § 117.1013 Kinsale Creek.

The draw of the state highway bridge, mile 4.0, at Kinsale need not be opened for the passage of vessels.

### § 117.1015 Mattaponi River.

The draws of the Lord Delaware (S33) bridge, mile 0.8 at West Point, and the S629 bridge, mile 28.5 at Walkerton, shall open on signal if at least 24 hours notice is given. The drawtender service for either bridge shall be increased to the degree determined to be adequate within 30 days after written notice is received from the District Commander to do so.

### § 117.1021 North Landing River.

The draw of the S165 bridge, mile 20.2 at Chesapeake, shall open on signal; except that, from 6 a.m. to 7 p.m., the draw need be opened only on the hour

and half hour for the passage of pleasure craft. Public vessels of the United States, commercial vessels, and vessels in an emergency endangering life or property shall be passed at any time.

### § 117.1023 Pamunkey River.

The draw of the Eltham Bridge (SR33/30) mile 1.0, located in West Point, Virginia shall open on signal if at least four hours notice is given at all times.

[USCG-2008-1175, 74 FR 29947, June 24, 2009]

### § 117.1025 York River.

(a) The Coleman Memorial bridge, mile 7.0, at Yorktown, shall open on signal; except from 5 a.m. to 8 a.m. and 3 p.m. to 7 p.m., Monday through Friday, except Federal holidays, the bridge shall remain closed to navigation.

(b) The bridge shall be opened at any time for vessels in an emergency which presents danger to life or property.

[CGD05-93-054, 59 FR 5954, Feb. 9, 1994, as amended by CGD05-95-023, 60 FR 31247, June 14, 1995]

## WASHINGTON

### § 117.1031 Chehalis River.

The draw of the U.S. 101 highway bridge, mile 0.1, at Aberdeen shall open on signal if at least one-hour notice is given at all times by telephone to the Washington State Department of Transportation.

[USCG-2009-0959, 75 FR 16004, Mar. 31, 2010]

### § 117.1035 Columbia River.

(a) The term *drawtender*, as used in this section means the operator of the drawspan, whether that person may be a train crew member, maintenance person, or an officially designated drawtender.

(b) The draw of the semi-automated Union Pacific railroad bridge (Kalan Bridge), mile 323.4, near Kennewick, Washington, is normally maintained in the fully open position with no drawtender in attendance. A radar beacon (RACON) is located at the center of the drawspan. The RACON operates only when the drawspan is fully open, by responding with the Morse letter “K” to X-band radar signals. When necessary to close the drawspan for the